

# VibrAlign Laser Alignment Tips

## Procedure for Calibrating the Touchscreen

1. Turn the unit on.
2. When the main screen comes on press and hold the red button while at the same time touching the upper right hand corner of the touchscreen.
3. After approximately 20-60 seconds the calibration screen should come up.
4. Begin calibrating the touchscreen by pressing the cross in the upper left corner. After pressing the cross another cross will come up in the upper right hand corner. Press this cross and each succeeding one.
5. After the last one is pressed the main menu will return.
6. The touchscreen is now calibrated.
7. If this procedure did not work your unit will have to be returned for repair.

